

INSTRUCTIONS FOR CHANGING THE STEM ON A SELECT-O-FLOW, SELECT-O-STREAM, OR MYSTERY STYLE MASTER STREAM NOZZLE

The following items are required: propane torch, #262 (RED) Loctite, fire/heat resistant gloves,
Stem (web) base wrench , & 4" Open Face Spanner.



80269001 – STEM WEB WRENCH

- Designed to hold the stem web (base) while removing and/or installing Master Stream heads
- Slotted end fits Select-O-Stream®, Select-O-Flow®, and Mystery® stem bases



71303001 – OPEN FACE 4" SPANNER WRENCH

- Removal and/or installation of stem heads on Master Stream nozzles (except X-Stream® series)

1. Place the nozzle in the wide fog position.
2. Clamp the stem (web) base wrench handle in a vice securely as shown.



3. From the inlet end of the nozzle heat the stem (web) base with a torch to break down the Loctite. Apply heat in the area where the stem and stem (web) base screw together. Use fireproof gloves and be careful not to burn yourself.



98465150 Rev-REL

4. Be careful not to burn yourself on the hot nozzle & place the nozzle down over the stem (web) base wrench and engage the stem (web) base in the wrench cut-outs.



5. Engage the pins of the open face spanner in the stem holes as far as possible and turn the wrench counter-clockwise to unscrew the stem from the stem (web) base.



6. Apply 262 (RED) Loctite to the threads on the new stem and thread it into the stem (web) base by hand to make sure the threads are engaged properly and not cross threaded. Screw the stem in until the shoulder bottoms on the stem (web) base and then snug it tight with the wrench. Allow the Loctite to cure for 24 hours before flowing water.