

ALTAIR® Multigas Detector Quick Start Card

Please review the back of this card for a detailed illustration of the following components:

① ▼ Button ② ▲ Button ③ ⏻ Button

- Charge battery until green LED is lit (rechargeable units only).
- Turn the instrument ON with the ⏻ button. Instrument performs a self test and sensor warm up, then displays sensor information & set points.
- A flow test must be performed during startup. Block pump inlet momentarily. See section 4.2 of the manual.
- Fresh Air Setup: press 'YES' or 'NO' buttons.
- To page through the screens, use the ▼ button from the Normal Operation screen; follow display instructions and press corresponding buttons to advance to next page.
- To reset alarms press ▲ button.
- Perform a Calibration Check daily for each installed sensor per section 3.8 of the manual.
- To Calibrate: ensure you are in fresh air and press and hold the ▲ button and follow instructions on the screen. See section 3.9 of the manual for complete calibration instructions.
- To activate / deactivate MotionAlert™ feature, use the ▼ button until MotionAlert screen appears, and follow display instructions.
- To activate InstantAlert™, press and hold ▼ button.
- Turn the instrument OFF by holding the ⏻ button.

WARNING

This quick start card provides only a brief description of the operating instructions for the ALTAIR 5 Multigas Detector Alarm. The user of this instrument must be fully aware of the limitations and instructions supplied in the operating instruction manual. Failure to follow the instructions may lead to serious personal injury or death.

MSA

**MINE SAFETY APPLIANCES COMPANY
PITTSBURGH, PENNSYLVANIA, U.S.A. 15230**

ALTAIR[®] 5

MULTIGAS INSTRUMENT

